

PLANET



Contents

Introduction	3
License	4
Installation	6
Usage tips	7
Sound list	8



Introduction

Planet V is a sound expansion library for Roland Fantom-S and Fantom-X series which is entirely based on an enormously large sample collection. This sound bank has been created using Roland's revolutionary V-Synth and V-Synth GT synthesizers, and it puts their groundbreaking sonic power into the high-polyphony sound engine of the Fantoms. The result will answer the question "can the Fantom sound really different?" with a definite "yes", and will blow away your expectations of what a sound library can be.

Polished and begging to play are synthesizers, basses, vocals and choirs, bells, electric pianos, pads and atmospheres, pulsating and rhythmically-modulated sounds, drum and percussion kits, beat loops, sound effects, vocoder voices, one-key arrangements and even more. Being a whole music production environment, Planet V includes a stunning variety of sounds, each of which exhibits our great passion for details and inspires new musical ideas.

Features

- 942 samples (110 MB)
- 64 multisamples
- 160 patches
- 14 rhythm kits

Compatibility

- Roland Fantom-S/S88
- Roland Fantom-X6/7/8
- Roland Fantom-XR
- Roland Fantom-Xa

Requirements

- Min. 128 MB RAM
- Min. 128 MB flash memory card

License

By using the Planet V sound library from Sinevibes, you accept the terms of this license agreement.

Scope of this license

This license applies to any and all files and materials featured in the Planet V sound library (further referred to as “Sound Library”).

License terms

- All materials included in the Sound Library are copyright ©2004-2007 Artemiy Pavlov, all rights reserved.
- You are allowed to use the Sound Library and all of its materials to compose original music for both non-commercial and commercial purposes, including, but not limited to, creation of melodies, mixes, compositions, jingles, soundtracks and the like.
- You can freely modify, process and tweak the Sound Library’s materials to fit your musical needs.
- Redistribution of the Sound Library materials in any way, by any means, on any media, in whole or part, in any form is strictly prohibited.
- Creating derivative sound libraries anyhow based on any part of the Sound Library is strictly prohibited.

Warranty

- The manufacturer guarantees that the Sound Library is a completely original work, not violating any laws, and not based on any illegal material.
- Although you will almost surely find our sounds awesomely useful, the manufacturer gives no guarantee for them to fit any particular purpose.
- The manufacturer shall have no responsibility in regard to any damage which may happen during the Sound Library installation or

use, including, but not limited to, steps taken due to misinterpretation or misunderstanding of the instructions given in this manual.

- The manufacturer is not obliged to keep support and provide future updates for the Sound Library, except for fixes for issues of corrupt data or improperly working sound materials.

Transferability

- You are free to transfer this license (i.e. sell the Sound Library) to any person, provided that no copy of any materials of the Sound Library remain at your side.

Installation

Notes on the instructions

- [ACTION] refers to a physical button, e.g. [MODE].
- "Action" stands for an onscreen button, icon, tab or menu option, e.g. "USB storage".
- Action 1 → Action 2 means you need to execute these actions consequently.

Installing Planet V

- Connect your synthesizer to your computer with a USB cable.
- Enter the USB storage mode:
 - **Fantom-S:** [MENU] → "USB".
 - **Fantom-X series:** switch to USB storage mode in [MENU] → "System" → "USB", then go to [MENU] → "USB storage".
- Select the "Card" area.
- On your computer, you will see a new removable drive which represents the Card flash memory area of the synthesizer.
- Using your computer, copy the **ROLAND** folder from Planet V to the Card area.
- Eject the removable drive using the options menu of the drive icon on your computer.
- Exit the USB mode on the synthesizer.
- If needed, disconnect the USB cable from the computer.
- Now, to load Planet V:
 - If the "User sample load" system option is activated, switch your synthesizer off, and then back on. Planet V will load automatically.
 - Or, eject and re-insert the card, and then select the "Load All Sample" function in the load menu.

Usage tips

Performance mode

When a patch is loaded into a performance, its effect settings are not automatically loaded. Although all Planet V patches are made to sound great without effects, in order to load the original effects settings you have to set the MFX source ("MFX SRC") parameter to the number of the part this patch is assigned to. You may want to do this to reverb and chorus processors as well.

Increasing polyphony

Certain Planet V patches include multiple mono or stereo partials (tones) to form a lush and rich sound. If you see such patches are eating too much polyphony, call up the tone switching menu in patch edit mode and turn some of the tones off, or convert them to mono mode by disabling the "Wave R" parameter in the "Wave" edit screen.

Sound list

Samples

EP Deluxe C1	Lo-Funk Bs F#2	Rocky Organ C5	SH Bass C6
EP Deluxe C2	Lo-Funk Bs F#3	Rocky Organ C6	SH Bass F#1
EP Deluxe C3	Lo-Funk Bs F#4	Rocky Organ F#1	SH Bass F#2
EP Deluxe C4	Mono Sync C2	Rocky Organ F#2	SH Bass F#3
EP Deluxe C5	Mono Sync C3	Rocky Organ F#3	SH Bass F#4
EP Deluxe C6	Mono Sync C4	Rocky Organ F#4	SH Bass F#5
EP Deluxe F#1	Mono Sync C5	Rocky Organ F#5	Synthi Bs C1
EP Deluxe F#2	Mono Sync C6	SBF Koto C1	Synthi Bs C2
EP Deluxe F#3	Mono Sync F#2	SBF Koto C2	Synthi Bs C3
EP Deluxe F#4	Mono Sync F#3	SBF Koto C3	Synthi Bs C4
EP Deluxe F#5	Mono Sync F#4	SBF Koto C4	Synthi Bs C5
FM EP 1 Lp C2	Mono Sync F#5	SBF Koto C5	Synthi Bs F#1
FM EP 1 Lp C3	Nordic Lead C1	SBF Koto C6	Synthi Bs F#2
FM EP 1 Lp C4	Nordic Lead C2	SBF Koto C7	Synthi Bs F#3
FM EP 1 Lp C5	Nordic Lead C3	SBF Koto F#1	Synthi Bs F#4
FM EP 1 Lp C6	Nordic Lead C4	SBF Koto F#2	Synthi Keys C2
FM EP 1 Lp F#2	Nordic Lead C5	SBF Koto F#3	Synthi Keys C3
FM EP 1 Lp F#3	Nordic Lead C6	SBF Koto F#4	Synthi Keys C4
FM EP 1 Lp F#4	Nordic Lead F#1	SBF Koto F#5	Synthi Keys C5
FM EP 1 Lp F#5	Nordic Lead F#2	SBF Koto F#6	Synthi Keys C6
FM EP 1 Lp F#6	Nordic Lead F#3	SBF Saw Detn C1	Synthi Keys F#2
FM EP 2 Lp C2	Nordic Lead F#4	SBF Saw Detn C2	Synthi Keys F#3
FM EP 2 Lp C3	Nordic Lead F#5	SBF Saw Detn C3	Synthi Keys F#4
FM EP 2 Lp C4	Power Juno C2	SBF Saw Detn C4	Synthi Keys F#5
FM EP 2 Lp C5	Power Juno C3	SBF Saw Detn C5	TB Saw Amp C1
FM EP 2 Lp C6	Power Juno C4	SBF Saw Detn C6	TB Saw Amp C2
FM EP 2 Lp C7	Power Juno C5	SBF Saw Detn C7	TB Saw Amp C3
FM EP 2 Lp F#2	Power Juno C6	SBF Saw Detn F#1	TB Saw Amp C4
FM EP 2 Lp F#3	Power Juno C7	SBF Saw Detn F#2	TB Saw Amp C5
FM EP 2 Lp F#4	Power Juno F#2	SBF Saw Detn F#3	TB Saw Amp F#1
FM EP 2 Lp F#5	Power Juno F#3	SBF Saw Detn F#4	TB Saw Amp F#2
FM EP 2 Lp F#6	Power Juno F#4	SBF Saw Detn F#5	TB Saw Amp F#3
Lo-Funk Bs C1	Power Juno F#5	SBF Saw Detn F#6	TB Saw Amp F#4
Lo-Funk Bs C2	Power Juno F#6	SH Bass C1	TB Saw Reso C2
Lo-Funk Bs C3	Rocky Organ C1	SH Bass C2	TB Saw Reso C3
Lo-Funk Bs C4	Rocky Organ C2	SH Bass C3	TB Saw Reso C4
Lo-Funk Bs C5	Rocky Organ C3	SH Bass C4	TB Saw Reso C5
Lo-Funk Bs F#1	Rocky Organ C4	SH Bass C5	TB Saw Reso F#2

TB Saw Reso F#3	Vawetable F#3	Vurli mp F#3	DX-V Bass C3
TB Saw Reso F#4	Vawetable F#4	Vurli mp F#4	DX-V Bass C4
TB Saw Shpr C1	Vawetable F#5	Vurli mp F#5	DX-V Bass C5
TB Saw Shpr C2	Vox 1 C2	V-106 Bs C2	DX-V Bass C6
TB Saw Shpr C3	Vox 1 C3	V-106 Bs C3	DX-V Bass F#2
TB Saw Shpr C4	Vox 1 C4	V-106 Bs C4	DX-V Bass F#3
TB Saw Shpr C5	Vox 1 C5	V-106 Bs C5	DX-V Bass F#4
TB Saw Shpr F#1	Vox 1 C6	V-106 Bs C6	DX-V Bass F#5
TB Saw Shpr F#3	Vox 1 C7	V-106 Bs F#2	Raw Shaper 1 C1
TB Saw Shpr F#3	Vox 1 F#2	V-106 Bs F#3	Raw Shaper 1 C2
TB Saw Shpr F#4	Vox 1 F#3	V-106 Bs F#4	Raw Shaper 1 C3
TB Saw Soft C2	Vox 1 F#4	V-106 Bs F#5	Raw Shaper 1 C4
TB Saw Soft C3	Vox 1 F#5	V-303 C2	Raw Shaper 1 C5
TB Saw Soft C4	Vox 1 F#6	V-303 C3	Raw Shaper 1 C6
TB Saw Soft C5	Vox 2 C2	V-303 C4	Raw Shaper 1 C7
TB Saw Soft C6	Vox 2 C3	V-303 C5	Raw Shaper 1 F#1
TB Saw Soft F#2	Vox 2 C4	V-303 C6	Raw Shaper 1 F#2
TB Saw Soft F#3	Vox 2 C5	V-303 F#3	Raw Shaper 1 F#3
TB Saw Soft F#4	Vox 2 C6	V-303 F#3	Raw Shaper 1 F#4
TB Saw Soft F#5	Vox 2 C7	V-303 F#4	Raw Shaper 1 F#5
TB Sqr C2	Vox 2 F#2	V-303 F#5	Raw Shaper 1 F#6
TB Sqr C3	Vox 2 F#3	V-Hammond C2	Raw Shaper 2 C1
TB Sqr C4	Vox 2 F#4	V-Hammond C3	Raw Shaper 2 C2
TB Sqr C5	Vox 2 F#5	V-Hammond C4	Raw Shaper 2 C3
TB Sqr C6	Vox 2 F#6	V-Hammond C5	Raw Shaper 2 C4
TB Sqr F#2	Vurli ff C1	V-Hammond C6	Raw Shaper 2 C5
TB Sqr F#3	Vurli ff C2	V-Hammond C7	Raw Shaper 2 C6
TB Sqr F#4	Vurli ff C3	V-Hammond F#2	Raw Shaper 2 C7
TB Sqr F#5	Vurli ff C4	V-Hammond F#3	Raw Shaper 2 F#1
TB Sqr LoFi C1	Vurli ff C5	V-Hammond F#4	Raw Shaper 2 F#2
TB Sqr LoFi C2	Vurli ff C6	V-Hammond F#5	Raw Shaper 2 F#3
TB Sqr LoFi C3	Vurli ff F#1	V-Hammond F#6	Raw Shaper 2 F#4
TB Sqr LoFi C4	Vurli ff F#2	Bass Shaper C1	Raw Shaper 2 F#5
TB Sqr LoFi C5	Vurli ff F#3	Bass Shaper C2	Raw Shaper 2 F#6
TB Sqr LoFi F#1	Vurli ff F#4	Bass Shaper C3	Raw LoFi Tri C1
TB Sqr LoFi F#2	Vurli ff F#5	Bass Shaper C4	Raw LoFi Tri C2
TB Sqr LoFi F#3	Vurli mp C1	Bass Shaper C5	Raw LoFi Tri C3
TB Sqr LoFi F#4	Vurli mp C2	Bass Shaper C6	Raw LoFi Tri C4
Vawetable C2	Vurli mp C3	Bass Shaper F#1	Raw LoFi Tri C5
Vawetable C3	Vurli mp C4	Bass Shaper F#2	Raw LoFi Tri C6
Vawetable C4	Vurli mp C5	Bass Shaper F#3	Raw LoFi Tri C7
Vawetable C5	Vurli mp C6	Bass Shaper F#4	Raw LoFi Tri F#1
Vawetable C6	Vurli mp F#1	Bass Shaper F#5	Raw LoFi Tri F#2
Vawetable F#2	Vurli mp F#2	DX-V Bass C2	Raw LoFi Tri F#3

Raw LoFi Tri F#4	Vox1 Num2	Hop Hat 1	LoFiHat 5 Cl
Raw LoFi Tri F#5	Vox1 Num3	Hop Hat 2	LoFiHat 5 Op
Raw LoFi Tri F#6	Vox1 Num4	Hop Kick 1	LoFiHat 6 Cl
Raw Sqr C1	132: Fbk Rhythm	Hop Kick 2	LoFiHat 6 Op
Raw Sqr C2	095: CrispyBreak	Hop Kick 3	Shaper Kick 1
Raw Sqr C3	156: DnB Loop 1	Hop Kick 4	Shaper Kick 2
Raw Sqr C4	154: DnB Loop 2	Hop Snare 1	Shaper Kick 3
Raw Sqr C5	116: FM Rhythm	Hop Snare 2	VP Click
Raw Sqr C6	056: Slooow Brk	Hop Snare 3	VP Cowb
Raw Sqr F#1	098: In Da Hood	Jngl Bass	VP Drum 1
Raw Sqr F#2	154: Jngl Hi Prc	Jngl Elem	VP Drum 2
Raw Sqr F#3	131: LoFi Break1	Jngl Hat	VP Drum 3
Raw Sqr F#4	120: LoFi Break2	Jngl Kick	VP Hat 1 Cl
Raw Sqr F#5	127: LoFi Mix	Jngl Snr	VP Hat 2 Cl
Punch Bass C1	102: Hop Hard	LoBit Hat	VP Hat 3 Cl
Punch Bass C2	120: Da Break 1	LoFi Beep	VP Hat 3 Op
Punch Bass C3	106: RnB 1	LoFi Clap	VP Hat 3 Pd
Punch Bass C4	114: RnB 2	LoFi Conga 1	VP Kick 1
Punch Bass C5	125: Da Break 2	LoFi Conga 2	VP Kick 2
Punch Bass F#1	125: Metal Hi	LoFi Hat 1 Cl	VP Kick 3
Punch Bass F#2	V-Bell	LoFi Kick 1	VP Kick 4
Punch Bass F#3	V-Chime	LoFi Kick 2	VP Kick 5
Punch Bass F#4	Brk Clang	LoFi Kick 3	VP Kick 6
FX X-Mod	Brk Cymbal	LoFi Kick 4	VP Kick 7
FX V-Water	Brk Hat Cl	LoFi Kick 5	VP Kick 8
Nz V-Bot	Brk Hat Op	LoFi Kick 6	VP Kick 9
Nz Chaos	Brk Hat Pd	LoFi Kick 7	VP Snare 1
Nz Digital	Brk Kick 1	LoFi Perc 1	VP Snare 2
Nz Electro	Brk Kick 2	LoFi Perc 2	VP Snare 3
Nz LoFi	Brk Rim	LoFi Rim	VP Snare 4
Nz Nuclear	Brk Shaker	LoFi Snare 1	VP Snare 5
Nz VariPhr 1	Brk Snare 1	LoFi Snare 2	VP Tom 1
Nz VariPhr 2	Brk Snare 2	LoFi Snare 3	VP Tom 2
TTP Freeze 1	Brk Tom 1	LoFi Snare 4	VP Tom 3
TTP Freeze 2	Brk Tom 2	LoFi Snare 5	V-606 Clang
TTP Freeze 3	Brk Tom 3	LoFi Snare 6	V-606 Clave
TTP Scratch 1	FM Clang	LoFi Tom 1	V-606 Conga
TTP Scratch 2	FM Cowbell	LoFi Tom 2	V-606 Cowbell
TTP Scratch 3	FM Drum 1	LoFiHat 2 Cl	V-606 Cymbal
TTP Scratch 4	FM Drum 2	LoFiHat 2 Op	V-606 Hat Cl
Vox1 Transm	FM Kick	LoFiHat 2 Pd	V-606 Hat Op
Vox1 AccessDe	Hop Beep	LoFiHat 3 Cl	V-606 Hat Pd
Vox1 Connect	Hop Cowb 1	LoFiHat 3 Op	V-606 Kick 1
Vox1 Num1	Hop Cowb 2	LoFiHat 4 Cl	V-606 Kick 2

V-606 LoFi 1	Tom LoFi 1	Vocoder 2 Num 2	Chord Synth 1
V-606 LoFi 2	Tom LoFi 2	Vocoder 2 Num 3	Chord Synth 2
V-606 Shaker	Tom LoFi 3	Vocoder 2 Num 4	Chord Synth 3
V-606 Snare 1	Vocoder 1 Hat	Vocoder 2 Num 5	Chord Synth 4
V-606 Snare 2	Vocoder 1 Kick	Vocoder 2 Num 6	Chord Synth 5
V-606 Tom 1	Vocoder 1 Snare	Vocoder 2 Num 7	Chord Synth 6
V-606 Tom 2	Vocoder 2 Clap 1	Vocoder 2 Num 8	Analog Bass 1 C1
V-606 Tom 3	Vocoder 2 Clap 2	Vocoder 2 Num 9	Analog Bass 1 C2
Drum Synth 1	Vocoder 2 Hat	Vocoder 2 Push	Analog Bass 1 C3
Drum Synth 2	Vocoder 2 Kick	Vocoder 2 Rocklt	Analog Bass 1 C4
Drum Synth 3	Vocoder 2 Snare	Vocoder 2 Shake	Analog Bass 1 C5
Hat Heavy 1	Vocoder 2 Tom	Vocoder 3 Dance	Analog Bass 1F#1
Hat Heavy 2	Vocoder 3 Hat 1	Vocoder 3 Groove	Analog Bass 1F#2
Hat Heavy 3	Vocoder 3 Hat 2	Vocoder 3 Num 0	Analog Bass 1F#3
Hat Light 1	Vocoder 3 Kick	Vocoder 3 Num 1	Analog Bass 1F#4
Hat Light 2	Vocoder 3 Snare	Vocoder 3 Num 10	Analog Bass 2 C1
Hat Light 3	Vocoder 3 Snare	Vocoder 3 Num 2	Analog Bass 2 C2
Kick Break 1	Vocoder 4 Clap	Vocoder 3 Num 3	Analog Bass 2 C3
Kick Break 2 A	Vocoder 4 Hat	Vocoder 3 Num 4	Analog Bass 2 C4
Kick Break 2 B	Vocoder 4 Kick	Vocoder 3 Num 5	Analog Bass 2 C5
Kick Break 3	Vocoder 4 Snare	Vocoder 3 Num 6	Analog Bass 2F#1
Kick Break 4	Vocoder 1 Dance	Vocoder 3 Num 7	Analog Bass 2F#2
Kick Break 5	Vocoder 1 Electr	Vocoder 3 Num 8	Analog Bass 2F#3
Kick Break 6	Vocoder 1 Groove	Vocoder 3 Num 9	Analog Bass 2F#4
Kick Break 7	Vocoder 1 Move	125: 2-Step 1	Analog Bass 3 C1
Kick Break 8	Vocoder 1 Num 0	130: 2-Step 2	Analog Bass 3 C2
Kick Break 9	Vocoder 1 Num 1	118: Breakbeat 1	Analog Bass 3 C3
Kick LoFi 1	Vocoder 1 Num 10	139: Breakbeat 2	Analog Bass 3 C4
Kick LoFi 2	Vocoder 1 Num 2	126: Breakbeat 3	Analog Bass 3 C5
Kick LoFi 3	Vocoder 1 Num 3	125: Electro 1	Analog Bass 3 C6
Scratch 1	Vocoder 1 Num 4	139: Electro 2	Analog Bass 3F#1
Scratch 2	Vocoder 1 Num 5	133: FX Beat 1	Analog Bass 3F#2
Scratch 3	Vocoder 1 Num 6	133: FX Beat 2	Analog Bass 3F#3
Scratch 4	Vocoder 1 Num 7	129: FX Beat 3	Analog Bass 3F#4
Scratch 5	Vocoder 1 Num 8	135: Latina	Analog Bass 3F#5
Scratch 6	Vocoder 1 Num 9	117: RnB 3	Analog Bass 4 C1
Snare Break 1	Vocoder 2 Dance	Atmosphere 1	Analog Bass 4 C2
Snare Break 2	Vocoder 2 Electr	Atmosphere 2	Analog Bass 4 C3
Snare Break 3	Vocoder 2 Groove	Atmosphere 3	Analog Bass 4 C4
Snare Break 4	Vocoder 2 Move	Chord EP 1	Analog Bass 4 C5
Snare LoFi 1	Vocoder 2 Movelt	Chord EP 2	Analog Bass 4 C6
Snare LoFi 2	Vocoder 2 Num 0	Chord Organ 1	Analog Bass 4F#1
Tom Cyber 1	Vocoder 2 Num 1	Chord Organ 2	Analog Bass 4F#2
Tom Cyber 2	Vocoder 2 Num 10	Chord Organ 3	Analog Bass 4F#3

Analog Bass 4F#4	GamelanBell 1 C4	Hard Wave 3 C5	Raw LA Sqr F#5
Analog Bass 4F#5	GamelanBell 1 C5	Hard Wave 3 F#1	Raw Sync C2
Digi Wave C2	GamelanBell 1 C6	Hard Wave 3 F#2	Raw Sync C3
Digi Wave C3	GamelanBell 1 C7	Hard Wave 3 F#3	Raw Sync C4
Digi Wave C4	GamelanBell 1F#2	Hard Wave 3 F#4	Raw Sync C5
Digi Wave C5	GamelanBell 1F#3	Hard Wave 4 C1	Raw Sync C6
Digi Wave C6	GamelanBell 1F#4	Hard Wave 4 C2	Raw Sync F#2
Digi Wave F#2	GamelanBell 1F#5	Hard Wave 4 C3	Raw Sync F#3
Digi Wave F#3	GamelanBell 1F#6	Hard Wave 4 C4	Raw Sync F#4
Digi Wave F#4	GamelanBell 2 C2	Hard Wave 4 C5	Raw Sync F#5
Digi Wave F#5	GamelanBell 2 C3	Hard Wave 4 F#1	Shadow Pad C3
FM Keys C2	GamelanBell 2 C4	Hard Wave 4 F#2	Shadow Pad C4
FM Keys C3	GamelanBell 2 C5	Hard Wave 4 F#3	Shadow Pad C5
FM Keys C4	GamelanBell 2 C6	Hard Wave 4 F#4	Shadow Pad C6
FM Keys C5	GamelanBell 2F#2	Naughty Bass C1	Shadow Pad F#3
FM Keys C6	GamelanBell 2F#3	Naughty Bass C2	Shadow Pad F#4
FM Keys F#2	GamelanBell 2F#4	Naughty Bass C3	Shadow Pad F#5
FM Keys F#3	GamelanBell 2F#5	Naughty Bass C4	Shaper Bass 1 C1
FM Keys F#4	Hard Wave 1 C1	Naughty Bass C5	Shaper Bass 1 C2
FM Keys F#5	Hard Wave 1 C2	Naughty Bass F#1	Shaper Bass 1 C3
FM-200 ff C2	Hard Wave 1 C3	Naughty Bass F#2	Shaper Bass 1 C4
FM-200 ff C3	Hard Wave 1 C4	Naughty Bass F#3	Shaper Bass 1 C5
FM-200 ff C4	Hard Wave 1 C5	Naughty Bass F#4	Shaper Bass 1F#1
FM-200 ff C5	Hard Wave 1 C6	Raw Saw C1	Shaper Bass 1F#2
FM-200 ff C6	Hard Wave 1 F#1	Raw Saw C2	Shaper Bass 1F#3
FM-200 ff C7	Hard Wave 1 F#2	Raw Saw C3	Shaper Bass 1F#4
FM-200 ff F#2	Hard Wave 1 F#3	Raw Saw C4	Shaper Bass 2 C1
FM-200 ff F#3	Hard Wave 1 F#4	Raw Saw C5	Shaper Bass 2 C2
FM-200 ff F#4	Hard Wave 1 F#5	Raw Saw C6	Shaper Bass 2 C3
FM-200 ff F#5	Hard Wave 2 C1	Raw Saw F#1	Shaper Bass 2 C4
FM-200 ff F#6	Hard Wave 2 C2	Raw Saw F#2	Shaper Bass 2 C5
FM-200 mp C2	Hard Wave 2 C3	Raw Saw F#3	Shaper Bass 2F#1
FM-200 mp C3	Hard Wave 2 C4	Raw Saw F#4	Shaper Bass 2F#2
FM-200 mp C4	Hard Wave 2 C5	Raw Saw F#5	Shaper Bass 2F#3
FM-200 mp C5	Hard Wave 2 C6	Raw LA Sqr C1	Shaper Bass 2F#4
FM-200 mp C6	Hard Wave 2 F#1	Raw LA Sqr C2	Shaper Bass 3 C1
FM-200 mp C7	Hard Wave 2 F#2	Raw LA Sqr C3	Shaper Bass 3 C2
FM-200 mp F#2	Hard Wave 2 F#3	Raw LA Sqr C4	Shaper Bass 3 C3
FM-200 mp F#3	Hard Wave 2 F#4	Raw LA Sqr C5	Shaper Bass 3 C4
FM-200 mp F#4	Hard Wave 2 F#5	Raw LA Sqr C6)	Shaper Bass 3 C5
FM-200 mp F#5	Hard Wave 3 C1	Raw LA Sqr F#1	Shaper Bass 3F#1
FM-200 mp F#6	Hard Wave 3 C2	Raw LA Sqr F#2	Shaper Bass 3F#2
GamelanBell 1 C2	Hard Wave 3 C3	Raw LA Sqr F#3	Shaper Bass 3F#3
GamelanBell 1 C3	Hard Wave 3 C4	Raw LA Sqr F#4	Shaper Bass 3F#4

Super Saw C1	Vox Duo C4
Super Saw C2	Vox Duo C5
Super Saw C3	Vox Duo C6
Super Saw C4	Vox Duo C7
Super Saw C5	Vox Duo F#2
Super Saw C6	Vox Duo F#3
Super Saw F#1	Vox Duo F#4
Super Saw F#2	Vox Duo F#5
Super Saw F#3	Vox Duo F#6
Super Saw F#4	Vox Ooo C2
Super Saw F#5	Vox Ooo C3
Super Square C1	Vox Ooo C4
Super Square C2	Vox Ooo C5
Super Square C3	Vox Ooo C6
Super Square C4	Vox Ooo C7
Super Square C5	Vox Ooo F#2
Super Square C6	Vox Ooo F#3
Super Square F#1	Vox Ooo F#4
Super Square F#2	Vox Ooo F#5
Super Square F#3	Vox Ooo F#6
Super Square F#4	Vox Too C2
Super Square F#5	Vox Too C3
Tibet Ice C2	Vox Too C3
Tibet Ice C3	Vox Too C5
Tibet Ice C4	Vox Too C6
Tibet Ice C5	Vox Too C7
Tibet Ice C6	Vox Too F#2
Tibet Ice F#2	Vox Too F#3
Tibet Ice F#3	Vox Too F#4
Tibet Ice F#4	Vox Too F#5
Tibet Ice F#5	Vox Too F#6
Vox Aaa C2	Vox Yaa C2
Vox Aaa C3	Vox Yaa C3
Vox Aaa C4	Vox Yaa C4
Vox Aaa C5	Vox Yaa C5
Vox Aaa C6	Vox Yaa C6
Vox Aaa C7	Vox Yaa C7
Vox Aaa F#2	Vox Yaa F#2
Vox Aaa F#3	Vox Yaa F#3
Vox Aaa F#4	Vox Yaa F#4
Vox Aaa F#5	Vox Yaa F#5
Vox Aaa F#6	Vox Yaa F#6
Vox Duo C2	
Vox Duo C3	

Patches

1 Planet V	41 Busty TB	81 V-Chimes	121 Ambisphere
2 Disco EP	42 Air Pad	82 Tru SH-101	122 V-Hoover
3 V-Groove	43 Hollow Lead	83 SciFi Synth	123 Vox Yaa
4 Plastik Bass	44 Naughty Bass	84 Teknosaur	124 Voco Beat
5 Neo Strings	45 Perky FM EP	85 Raw Sync	125 DX-7 Bass
6 Nordic Lead	46 Plastic 303	86 Elastic Bass	126 SuperSaw Pad
7 DX-7 EP	47 FM Bass 1	87 V-tron Ens.	127 'coder Menu
8 TB Classique	48 Fast Seq	88 Cheesy Sqr	128 FM Keys
9 Tekno Hoover	49 Power Synth	89 LP Noiz	129 Bass Attack
10 Hammondize	50 V-Stream	90 Boomy Break	130 Vox Morpher
11 Twilight Pad	51 TB Amp	91 Trapezoid Bs	131 LostInDelays
12 ModToFreeze	52 Buzzer Bass	92 Fairy Bells	132 Electri-fy
13 Soft EP	53 Star Pad	93 Retro Brass	133 Rock It
14 EtherVox 1	54 Vurlitzer	94 Big Synth	134 DanceWithMe
15 Lo-Funk Bass	55 Lectro 33	95 Pulsar Pad	135 Mighty Bass
16 Vawe Pad	56 SH-1 Bass 2	96 Mono Phatt	136 Moon Pad
17 Old Vurly	57 Synsphere	97 FM-200	137 Voco Synth
18 Space Koto	58 Digi EP	98 Synchrotron	138 Jazzy
19 Juno-106 Bs	59 Synthie 60	99 SH-2 Bass	139 Vox-o-rama
20 Mono Sync	60 Goa Needle	100 Vox Too	140 Hue G.
21 Raw 303	61 Bass Shaper	101 Ultra Hoover	141 V-Power
22 Synthi Bass	62 Crystal EP	102 GamelanBell1	142 FM FM FM
23 EP Deluxe	63 Aqua Tune	103 Shadow Pad	143 Jet Vox
24 Rockin` B 1	64 Morph Shaper	104 Elektro Bass	144 Ultrabeat
25 TB LoFi	65 1keyInDaHood	105 Analog Bass1	145 Dreamy EP
26 Dark Finger	66 Alien Base	106 Analog Bass2	146 Pulse Plus
27 V-50	67 Retrorgan	107 EtherVox 2	147 Future RnB
28 Power Break	68 FM Bass 2	108 Disco Attack	148 The Blade
29 Synthi Keys	69 V-Lectro	109 1-2-3-Dance	149 Dirty.org
30 Juno Strings	70 Vintage Stab	110 MG Pusher	150 CrossfadeVox
31 SH-1 Bass 1	71 Padshine	111 V Ensemble	151 Diamond Pad
32 Mod Chirper	72 Digi Bell	112 Tibet Ice	152 Multimega
33 Ring Shaper	73 Da Lowz	113 Motion Vox	153 V-Strings
34 Klubb Tune	74 Soft TB	114 Filterscape	154 Nordic Bass
35 Wet Rhodes	75 Juno Ens.	115 Hardy Hard	155 Falling Star
36 Kick Bass	76 Garage Base	116 GamelanBell2	156 Gated Vox
37 Cosmochoir	77 Wet Wurli	117 Trance Saws	157 303 v/s
38 Rockin` B 2	78 Heavenly Vox	118 Planet Vibe	158 Hard 5th
39 Next Level	79 R and B	119 FM Bass 3	159 Arp'd Square
40 Punchy Bass	80 Gritty 303	120 Digi Pad	160 Clubsphere

Rhythm kits

- 1 Vari Kit
- 2 Lo-Fi Kit
- 3 NuHouse Kit
- 4 V-606 Kit
- 5 Hard Hop Kit
- 6 DrumNBassKit
- 7 RnB Kit
- 8 FX Menu
- 9 Techno Kit
- 10 Beat Menu
- 11 VocoDrumMenu
- 12 VocoVox Menu
- 13 Break Kit
- 14 Bitbox Kit